

- 1- Mount striker to gate
- 2- Mount latch to post
- 3- Adjust gate, hinges and striker bar



