

Plucking machine

For plucking feathers from poultry such as ducks, chickens and geese

CE ✓ RoHS



MADE OF STAINLESS STEEL + PA PARTS

VERY STABLE CONSTRUCTION



 **Made in Holland**

Assemblage

1 Assembling the four legs

At the top of the box you will find four legs of stainless steel. Remove the protection foil from the legs and leave the plucking machine in the box. Remove the two top pieces of protective material. The plucking machine should be packed upside down in the box. Now you can easily click the four legs into the plastic corner pieces of the plucking machine.

2 Turning the plucking machine

Make sure the legs are locked. Then turn the machine as a whole and place it on a flat and solid surface.

Before usage



Read the instructions before you use the plucking machine.

- ❗ Place the plucking machine on a flat and solid surface.
- ❗ Choose carefully the clothes you wear, we recommend that you do not wear loose or baggy clothing. If you have long hair, make sure that you have tied up your hair.
- ❗ Make sure to use a grounded outlet.
- ❗ Make sure that the poultry you want to pluck has been in a scalding kettle with hot water. The temperature of the water should be around 55 – 70 °C. The pores of the animal will open due to the warm water, the feathers can be more easily picked.
- ❗ Below the on/off button, you will find a red emergency button. In case of problems, you can press this red button. This will stop the power supply immediately and therefore the motor of the plucking machine stops. To reset the machine, just turn the button after which the button emerges.



Using the plucking machine

- 1 Connect the plucking machine to a grounded outlet. The cable of the plucking machine is 2.5 m long, use this length to ensure that the plucking machine stands as far as possible from the electrical socket.
- 2 When you press the green button, the motor starts running. Keep the poultry in the plucking machine drum, on the opposite side of where you stand. Hold the poultry firmly and move the animal to remove all feathers.
- 3 When the animal is completely plucked, you can turn off the plucking machine by pressing the red off button. Make sure that you do not press the emergency button!



After using the plucking machine

- ! Clean the plucking machine drum and the plucking fingers with warm water.
- ! The plucking machine must be completely dry before you store the plucking machine.
- ! Make sure that you do not wet any electrical components of the plucking machine.
- ! Make sure that you store the plucking machine in a dry place!

Replacing the plucking fingers

- 1 Take the plucking fingers one by one out of the plucking machine by pulling it out.



- 2 Take a screwdriver and push the fingers with this screwdriver in the drum. As shown in picture beside.



This plucking machine comes with 30 plucking fingers. New plucking fingers are separate available.



Optional product - PM-OB1-P01



PRODUCT DETAILS

Art. code	Tech. specs.	Description	Size and weight
PM-OB1	0.5HP/900RPM	Capacity 30-40 birds/hour	85 x 67 x 79.5 cm
	220-240VAC/50Hz	Made of stainless steel + PA parts	21 kg
	Thermal protected	Very stable construction	
	Emergency stop		
PM-OB1-P01		Plucking finger soft TPR / Red	L 92 mm / 34 g